

**Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills
TROUBLESHOOTING GUIDE**

Symptom: Display reads "Notify Maintenance" "Waxer Disconnect"

SECTION I

Malfunction	Probable Cause	Corrective Action
<p>Waxer Disconnect</p>	<p>Wax assembly electrical line cord</p> <p>3 amp breaker popped / faulty</p> <p>Faulty CPU Control Board</p>	<ul style="list-style-type: none"> <input type="checkbox"/> Verify waxer cable is plugged into electrical outlet on front frame assembly. <input type="checkbox"/> Using an Ohm Meter, check continuity on waxer cable and plug <input type="checkbox"/> Check 3 amp breaker. <input type="checkbox"/> Test circuit breakers. Replace if necessary. <input type="checkbox"/> Swap CPU with another 9100 model treadmill. Replace CPU control board <p style="text-align: right;">Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737</p>

*All treadmills (U.S. and Canada) require a 120v 20amp dedicated line.