

Life Fitness 9100 Series Heartrate and Telemetry Equipped Treadmills **How To...REMOVE AND REPLACE THE TRANSFORMER**

Tools Required: Standard screwdriver, hex key wrench set, wire cutting tool

Step 1

Turn the power OFF at the switch and by unplugging the unit at the electrical outlet.

Step 2

Remove the four SCREWS securing the MOTOR COVER in place and set COVER aside.

Step 3 (Figure 1)

Pull out the two RUBBER MOUNTING NUTS holding the FRONT PROTECTOR SHIELD in position and remove it from the machine.

Step 4 (Figure 1)

Remove the four SCREWS securing the FRONT COVER in place.

Step 5

Unplug the two CONNECTORS and cut any WIRE TIES securing the worn TRANSFORMERS' WIRE HARNESS to the Treadmill FRAME.

Step 6 (Figure 2)

Remove the two SCREWS securing the worn TRANSFORMER to the POWER BOX and replace with a new TRANSFORMER.

Step 7

Reverse Steps 1 through 5 to return all parts to their proper position.

NOTE: BE SURE TO REPLACE ALL WIRE TIES TO SECURE THE WIRE HARNESS TO THE FRAME IN ITS ORIGINAL POSITION.