

Error Log (Plus Models only)

This feature records any error condition and the distances (in miles) when the error occurred. In case of multiple errors, only one is logged. If the distance has not been incremented from the last error, new errors will not be logged until the belt has been started and stopped (stopping logs the distance). The display will log eight of the most recent events from the top down. When the ninth error occurs, it will overwrite the top event, on back over the previous eight.

You can clear the Error Log during a service visit by pressing **Clear Log** in the Log screen. After clearing the log, the screen will return to the prior menu.

Pressing **Return** does not affect the Log but will return you to the previous menu.

Speed/Grade (Open-Loop Mode, ClubTrack 510/612 only)

In Service mode, the treadmill operates as in open-loop mode, which is used to verify treadmill speed or grade. In this mode, the treadmill displays the actual speed or grade, rather than the target speed or grade.

Approximate speed and grade ranges:

Treadmill Model	Speed Range	Grade Range
ClubTrack 510/510 Plus	1.0 to 10.0 mph (1.6 to 16 km/h)	0 to 12%, 0 to 6.84°
ClubTrack 612/612 Plus	1.0 to 12.0 mph (1.6 to 19.3 km/h)	0 to 15%, 0 to 8.53°

Speed (Direct Speed Control)

1. Enter the service mode.
2. Press **Up**, **Faster**, and **Slower** simultaneously to enter open-loop speed mode.
3. Press **Stop Belt**, **Faster**, and **Slower** simultaneously to exit the service mode; do not press the **Power** key.
4. Ensure that no one is standing on the walking belt, then press Start Belt.
5. Press and hold Faster or Slower to change the speed.
6. When testing is finished, press Clear, or press Power twice to exit open-loop mode.

Grade

1. Enter the service mode.
2. Press **Faster**, **Up**, and **Down** simultaneously to enter open-loop grade mode.