

Service Menu

To access Maintenance Mode:


1. While in **Home Screen**, press and hold “**VOL +, CH/TRK +, and 3**” simultaneously.
2. A pop up window appears requesting a Password.
3. Enter the Managers Password **218** to gain access to the **Service Menu**.



Once in Service Menu you can open the following menus:


MAINTENANCE MODE - while in Maintenance Mode, the following information can be access and/or modified:

- SW versions - The latest software version loaded in the system.
- Serial Number - The last five digits of the display serial number.
- Model - The product type (treadmill, bike, etc.)
- Units - The units of measurement English or Metric
- Language - The language selected at setup
- Max Time - The maximum time allowed for a single workout
- Weight - The default user weight used for Quick Start programs
- Oper Hours - The cumulative amount of usage hours
- Dist Logged - The cumulative distance logged
- METs Display - Allows the manager/owner to select the METs Availability (ON or OFF)
- Pause Time - Allows the manager/owner to select the length of the pause (30, 45, 60, 90, or 120 seconds)
- Auto Fan - Allows the manager/owner to select the Auto Fans Functionality (ON or OFF)
- Lock out - Allows the manager/owner to select the Lock Out Function (ON or OFF)
- Max Speed - English (From 5.0 to 15.0) or Metric (From 5.0 to 24.1)
- Accel Time - Allows the manager/owner to set Acceleration Time of treadmill (From 25 to 60)
- Decel Time - Allows the manager/owner to set Deceleration Time of treadmill (From 20 to 60)
- User Detect - Availability (ON or OFF)
- UD Threshold - Displays user detect feature threshold values.




MANAGER MODE

Allows the change of Units, Language, Max Time and Weight.



DIAGNOSTICS MODE

Allows the test of all hard keys, and the telemetry and contact heart rate.



USAGE STATISTICS

Displays the total number of times a program has been used.

