

## Life Fitness 9100 Series Heartrate and Telemetry Equipped Treadmills How To...REMOVE AND REPLACE THE TELEMETRY / HR KIT

**Tools Required:** Phillips screwdriver

---

### Step 1

Turn the power OFF at the ON/OFF switch and by unplugging the machine at the electrical outlet.

### Step 2

Use a Phillips screwdriver to loosen and remove the two SCREWS securing the TELEMETRY/HEART RATE SENSOR COVER to the bottom of the CONSOLE PAN.

### Step 3

Gently pull on the WIRE HARNESS protruding from the CONSOLE PAN to provide some slack in the line. Remove the TELEMETRY/HEART RATE RECEIVER from within the protective foam and unplug the RECEIVER from the receptacle on the WIRE HARNESS.

### Step 4

Install the new TELEMETRY/HEART RATE RECEIVER by reversing Steps 1 through 3 to return all parts to their proper position.

**NOTE: BE CAREFUL NOT TO PINCH ANY WIRES BETWEEN THE CONSOLE PAN AND THE TELEMETRY/HEART RATE SENSOR COVER DURING INSTALLATION.**

