

<b>MATRIX</b>	Service Bulletin: Upgraded handlebar foam for the Matrix elliptical	
	Prepared by: Eric Chen	Date Prepared: 2/4/2015

## DESCRIPTION

Matrix has released upgraded handlebar foam for ellipticals that develop rust:



**Figure A**

## REASON

Rust develops because sweat accumulates and infiltrates into the handlebar (Figure A).

## SOLUTION

1. JHT has changed the handlebar foam by increasing the length to 590mm and diameter to 32mm. This prevents sweat infiltration.
2. The new foam is only used for field service.
3. The new foam is part number **1000359769**. The specifications are  $\Phi 32 \times 3 \times 590$ L (Figure B).

4. The new application is available starting from February 2015.
5. The affected models are shown in Table 1 below:

**Table 1: Affected S/N list**

Area	Model S/N	
ID	E3XC	PEP301-KM
	E5XC-6	PEP74-KM
	E5X/E7X/E7XE-F	PEP81-KM-F
US	E3XC-01	PEP301-US
	E5XC-06	PEP74-US
	E5XC-F	PEP81-US-F



**Figure B**