

Warranty Information

WARNING

Store indoors only.Do not subject machine to high hum idity ordam p conditions.

Nautilus[®] XP Load™ Variable Resistance W arranty Lim ited W arranty Term s & General Specifications

Nautilus warrants only to the original purchaser that Nautilus® commercial exercise equipment from the manufacturer is free from defects in material and workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or exchange at our plant (a) of any part or parts of the structural frame, moving weldments or weight stacks which may thus prove defective under normal use and service for 12 years from delivery to the original purchaser; (b) of any moving part or parts not otherwise disclosed within this warranty which thus may prove defective under normal use and service within one (1) year from delivery to the original purchaser; and (c) of any upholstery, pads, grips or tethered weight pin connectors which thus may prove defective under normal use and service within 6 months from delivery to the original purchaser. This warranty only applies to those parts that our own examination discloses to our satisfaction to be thus defective. Nautilus will replace, free of charge, safety /caution decals which are missing or damaged.

Nautilus Equipm ent Warranty

2ST, N itro Plus/N itro, XP Load, and Free W eights

12 Years To original owner for frames, welded moving parts and weight stacks.

3 Years To original owner under normal use and service for any moving part or parts not otherwise

disclosed in this warranty.

1 Year Laborwarranty - To original owner.

6 m on the II nholetery nade arrive and tethered weight stack nine

Equipm entschem atics available online atwww nautilus.com for faster repair diagnosis and

parts delivery.

This warranty is expressly in lieu of all otherwarranties, express or implied, including the warranties of merchantability and fitness for use and of all other obligations or liabilities on our part, and we neither assume nor authorize any other person to assume for usary other liability in connection with the sale of this NAUTILUS® commercial exercise equipment. This warranty shall not apply to this NAUTILUS® commercial exercise equipment or to any part thereof which has been subject to accident, negligence, alteration, abuse, misuse, or a lack of maintenance in accordance with our recommended maintenance instructions. We make no warranty whatsoever in respect to accessories or parts not manufactured by us and disclaimally arranties, express or implied, as to such accessories and parts. The term "original purchaser", as used in this warranty, shall be deemed to mean that person or entity for whom this NAUTILUS® commercial exercise equipment is originally installed. This warranty shall apply only within the boundaries of the continental United States.

NAUTILUS® shall not be liable for any loss or dam age, including incidental or consequential dam ages resulting directly or indirectly from the use or loss of use of our NAUTILUS® commercial exercise equipment. Without limiting the generality of the foregoing, this exclusion from liability embraces the purchaser's expenses for downtime or formaking up downtime, damages for which the purchaser may be liable to other persons, damages to property, and injury to ordeath of any persons. We neither assume not authorize any person to assume for us any liability in connection with sale or use of our equipment. There are no oral agreements or warranties collateral to or affecting this agreement.

Dealer Acknowledgment Notice:

Nautilus CommercialWarranty times begin 30 days after product has been shipped from our manufacturing plant to your warehouse or storage site, unless otherwise specified at time of customer pickup.

ONAUTILUS

Maintenance INSTRUCTIONS

For XP Load Strength Training
Equipm ent



Getting maximum results from Nautilus[®]
machines depends on proper
maintenance of equipment.

Welcome

Congratulations on choosing Nautilus® XP Loadrm strength training equipment. The addition of several exciting new features to the Nautilus® line, as outlined in these instructions, ensures that your equipment will operate with little scheduled maintenance. We know this is important to you and your customers, so please take a few minutes to read the following instructions for keeping your Nautilus® equipment in the bestworking condition.

Contents

W elcom e	1
Parts & Service	1
SafetyBefore Exercising	2
Maintenance Schedule	2
GeneralMaintenance	3
M ini-W eightStack P in Replacem ent	3
C baning	3
Lubrication	3
W arranty Inform ation	4
-	

Parts & Services

Regularand scheduled maintenance willprobing the life of your Nautilus equipment. Should you have to replace parts, use only genuine Nautilus parts. The Nautilus Customer Service Team invites you to call in your order for replacement parts. They're never too busy to discuss or offer a tip on your maintenance tasks.

Nautilus machines — the culm ination of years of research and refinement—are made from the highest quality materials, under exacting conditions. The quality control tag attached to each machine before shipping ensures that each unit has been thoroughly inspected to meet Nautilus' strict requirements.

Should you, the owner of a Nautilus machine, need to replace any parts because of normal wear and tear, or should your machine ever need maintenance, Nautilus invites you to call our Virginia Headquarters office for information on parts and service.

Nautilus has available: detailed isom etric drawings on the website @ www nautilus.com for each machine manufactured, genuine Nautilus U pholstery Pads, Naugahyde® Spray C leaner/C onditioner recommended for Nautilus upholstery pads and TFL #50 WetLubricant recommended for the care of the quide rods of Nautilus selectorized resistance machines.

Nautilus' concern for the custom erdoes not end with the purchase of equipment. Your comments are always welcomed. In the unlikely event that a problem occurs, call us toll free:



Nautilus Custom erService 800-NAUTLUS Fax:276-773-2298

Safety

- 1. Supervision is necessary when the machine is used by ornear children, invalids, or disabled persons.
- 2. Follow the instructions for specific exercises on each machine
- 3. Get in and out of the equipm ent carefully.
- 4. Never operate the machine without shields in place.
- 5. Use only Nautilus selectorpins in weight stack. Never drop or insertany other object into machine opening.
- 6. Use this machine only as intended ordescribed in this manual.
- 7. Do not operate equipm entwith loose ordam aged parts. If m achine fails to operate correctly, do not attempt to repair. Notify authorized personnel of the problems.
- 8. Keep hands and feet clear of weights and otherm oving parts when in use. Keep hands and feet only on the hand grips and footpads provided.
- 9. Failure to comply with these instructions may result in personal injury.

Nautilus will replace, free of charge, safety /caution decals which are missing ordamaged.

Before Exercising

To guard againstinjury, all equipm entusers should follow these instructions.

- \ensuremath{n} Check with your physician and get approval before beginning a training routine.
- n Become familiarwith the equipment before beginning a training routine.
- \ensuremath{n} A lw $\ensuremath{\text{ays}}\,\ensuremath{\text{w}}$ arm $\ensuremath{\text{-up}}$ before and cooldow \ensuremath{n} after exercising.
- \ensuremath{n} M ove slow by during each exercise. Do not jerk or "throw" the weight.
- n Breathe freely. Do not hold your breath while lifting or low ering weight.
- n Holdmovementams and handles firmly, do not squeeze organip tightly.
- \ensuremath{n} Structure each w orkout to exercise the largest m uscles first. Suggested routines are found in the N autilus TotalFitness Program .
- n Experim ent to find the exact weight you need for each exercise. Select a resistance that allows you to perform eight to twelve slow repetitions. Take two seconds to lift the weight. Pause briefly, and take four seconds to lower the weight.

CAUTION

Stop exercising in mediately if you experience a sharp nerve or jointpain, and seek medical advice.

Maintenance Schedule

	DAIY	W EEKLY	MONTHLY	EVERY 6 MONTHS
GeneralMaintenance				
Check Safety & Warning Decals	n			
InspectBelts & Cables	n			
SpotCheck Belt			n	
SpotCheck Nuts and Bolts			n	
SpotCheck All Pegs and Stops			n	
Exam ine Rotation Points				<u>n</u>
Cleaning				
C lean Upholstery	n			
Use Quick FillA-33 Disinfectant Cleaner.				
Clean Surface Area		<u>n</u>		
Remove Dust				n
Lubrication				
Lubricate and Clean Guide Rods Using TFL 50		n		
Do not lubricate hydraulic cylinders.				

GeneralMaintenance

Frequency of maintenance is determined by several factors: temperature, humidity, use, ventilation and filtration, shielding and friction. External maintenance may vary from daily to monthly, internal maintenance from six months in a club environment to a year when used in a multi-user setting.

- 1.SPOT CHECK LOOSE NUTS AND BOLTS
- A . C arefully check rotation points.
- B. Tighten loose parts im m ediately. A lso check forw orn parts, seat belts and upholstery pads.
- 2.UPHOLSTERY PAD TIGHTEN ING

 Mostbolts on upholstery pads can be tightened with a 9/16"

 combination wrench.
- 3.SH ELD REMOVAL

Some Nautilus® machines are equipped with quick-release shield fasteners. To remove Quick-Release shielding, gently pull shielding away from the frame. Use a proper screw driver to remove shield, which is attached to the frame with screws.

4.SHELD INSTALLATION

Snap Quick-Release in place. Tighten screws only snugly. Use correct phillips screw driver.

Lubrication

MOVING PARTS

To clean and lubricate guide rods, apply TFL #50 W et Lubricant to a clean cloth then use to wipe rods.



*TFL 50 W et Lubricant Recom m ended for Nautilus Machines.

W ARNING Donotlubricate M INIW EIGHTS May cause damage and VOID

MaycausedamageandVOID WARRANTY.



Do notplace equipmentin directsunlightas ulha violet mays can damage shields and upholstery.

Cleaning

- 1.UPHOLSTERY CLEANING AND PROTECTION
 - A.Keep pads free of perspiration at all times.
 - B.C lean and disinfect upholstery at the end of each day, especially areas where perspiration and scalp oil collect.
 - C.Clean alloutside surfaces with non-abrasive, nonchlorinated household cleaners. Virahol® Disinfectant Cleaner is an effective upholstery care product.
- 2.CLEANING AND CARE OF PAINTED SURFACES
 - A .W ipe painted surfaces with a dam p cloth and carwax.
 - B.Letdry and buffw ith a dry cloth.

19-1175

OUK FLLA-33

Detergent Disinfectant Odor Counterac



An Outstanding liquid quaternary-based product for use in areas where there's heavy soiling. Provides the best odor counteraction available from a disinfectant. Available in ready-to-use; no mixing ordilution 16 oz.spray bottle. USDA Code 1, EPA Reg. 42964-

TO PLACE AN ORDER

Give our friendly Custom er Service Representatives a call to order this productor any other Genuine Nautilus Parts

1-800-235-2233

3