Lift Motor

Life Fitness Models 9100, 9500HR, 9700HR, and 9700HR w/Decline Treadmills How To... Replace The Lift Motor

Tools Required: Phillips screwdriver, socket set, pliers

Step 1

Turn the unit power OFF at the switch, then unplug the line cord at the wall outlet.

Step 2

Remove four phillip screws from the MOTOR COVER, and lift off the MOTOR COVER.

Step 3

Cut-off cable ties.

Step 4

Disconnect the 4-PIN CONNECTOR from the WAX PCB.

Step 5

Disconnect LIFT MOTOR ground wire from the POWER MODULE.

Step 6

Remove the RIGHT ACCESS PANEL on the right side of the unit, and tilt the unit over on its right side.

Step 7

Remove the 3/8-16" mounting bolt and nut from the LIFT FRAME.

Step 8


Remove the clip and pin from the lift motor, and remove the lift motor.


Step 9

To install the lift motor, make sure that the lift carriage is activating the level switch on 91/95, and on the 97 the decline switch. If necessary adjust THREADED SHAFT TUBE until the mounting bolt holes are 13-3/4" apart or aligned with the carrier and lift motor.

Step 10

Refer to diagnostics section to log maintenance repair of the lift motor.





Threaded Shaft Tube/

Pin