Procedure 7.26 - Replacing a Handlebar

- 1. Set the on/off switch in the ioffî position, then unplug the power cord from the wall outlet.
- 2. Loosen the screws that fasten the upper end of the handrail into the upper handrail clamp.
- 3. Loosen the four set screws that fasten the lower end of the handrail into the frame tube.
- 4. Slide the upper end of the handrail out of the upper handrail clamp and then slide the lower end of the handrail off of the frame tube.
- 5. Slide the upper end of the replacement handrail into the upper handrail clamp and then insert the lower end of the handrail onto the frame tube mount.
- 6. Tighten the upper handrail screws and lower handrail set screws.