

Pedal Design Change

SC916 and SC5

This document explains the change that was made to the SC916 and SC5 model pedals.

On the previous pedal design, there have been reports the flaps on the pedals were detaching or tearing from the upper portion of the pedal (Fig. 1 and Fig. 2).



Fig. 1



Fig. 2

StairMaster has made a design change to eliminate the previous issue. The newly designed part numbers are

- 055-0089, left pedal assembly
- 055-0093, right pedal assembly

Note: Please order BOTH left and right to get a matching set.

The new design provides a secure pad with no additional rubber on the pedal (Fig. 2). As Fig. 3 and Fig. 4 show, there are no flaps of plastic between the top of the pad to the base of the pad.



Fig. 3



Fig. 4