


HOIST[®]
FITNESS SYSTEMS

S202

**RIGID ARM
LAT PULLDOWN**




CUSTOMER CATALOG

SEPTEMBER '95


S202

RIGID ARM LAT PULLDOWN Frame Assembly





S202

RIGID ARM LAT PULLDOWN Upholstery & Grip Assembly



S202


RIGID ARM LAT PULLDOWN Cable




S202

RIGID ARM LAT PULLDOWN Cable Diagrams


Step 1 - Attach Clevis to the Main Upright then thread the cable around the pulley on the side of the Arm Assembly.




Step 3



Step 2




Step 4



S202

RIGID ARM LAT PULLDOWN Shields



PARTS LIST

Key No.	Qty.	Part Number	Description
1	1	61-S202012	BENCH ASSEMBLY
2	1	61-S20207	BASE FRAME
3	1	61-S202022	MAIN UPRIGHT
4	1	61-S20209	UPRIGHT SUPPORT
5	1	61-S20204	WEIGHT BASE
6	1	61-S20203	WEIGHT TOP
7	1	61-S20210	CROSSMEMBER ASSEMBLY
8	1	61-S20205	ARM ASSEMBLY
9	1	61-S20206	THIGH PAD MOUNT
10	1	14-BSH-GRD-34	GUIDE ROD SNAP BUSHING
11	2	26-STD-SG106	3/4" Dia. x 71 3/4" GUIDE ROD
12	1	26-STD-SWTOP-1	8 1/2 Lb. TOP WEIGHT PLATE w/STEM
13	20	26-STD-SW101	12 1/2 Lb. WEIGHT PLATE
14	2	19-WSB-123	1/2" RUBBER DONUT
15	2	14-BRG-RAD1PILP	PILLOW BLOCK BEARINGS
16	4	19-GRP-78514T	TAPERED GRIP
17	1	26-STD-SM128	1/2" PULL PIN (SHORT)
19	1	18-PUL-412	4 1/2" PULLEY
20	2	26-STD-SSH119	71 3/4" SHIELDS
21	1	26-STD-SU815	8" x 15" SEAT PAD
22	2	26-STD-SU606	6" x 6" THIGH PAD
24	1	61-S20212	CROSSMEMBER, BASE FRAME
25	1	610S20211	CROSSMEMBER, WEIGHT CAGE
26	1	61-S20213	FOOTREST ASSEMBLY
27	2	26-STD-PLAS128	8 1/2" Lg. KNURLED PLASTIC
28	2	26-STD-PLAS112	EASY GLIDE ADJUSTER SLEEVES
29	1	16-CAP-GRD1	1" ROD CAP
30	2	16-CAP-12	1" x 2" END CAP
31	3	16-CAP-22	2" x 2" END CAP
32	1	16-CAP-112112	1 1/2" x 1 1/2" END CAP
33	2	26-STD-PLAS114	1/2" FLANGED PULLEY SPACER

