

Life Fitness Model 8500, 9100, and 9500HR Cross-Trainers How To... Replace The Rear Wheels and Axle

Tools required: Slotted screwdriver and Pliers

1. Remove the AXLE CAP from the WHEEL AXLE.
2. Remove the WHEELS and AXLE.
3. Install new wheels, axle, and axle cap in the reverse direction.

