

Life Fitness Model 8500, 9100, and 9500HR Cross-Trainers How To... Replace The Intermediate Pulley

Tools required: 3/8" Socket set and Standard wrench set

1. Remove the REAR COVERS. See How To... Remove Rear Covers.
2. Loosen the ALTERNATOR PIVOT BOLT and rotate the alternator down to relieve belt tension.
3. Loosen the belt tension on the INTERMEDIATE PULLEY by loosening the five(5) bolts on the ALTERNATOR MOUNTING BRACKET.
4. Remove the INTERMEDIATE SHAFT BOLT and the INTERMEDIATE PULLEY.
5. Install new INTERMEDIATE PULLEY in reverse order.

