## **Procedure 7.10 - Replacing the ON/OFF Switch**

(version 1,2 units manufactured before 10-16-2000)

## Removing the ON/OFF Switch

Set the on/off switch in the ioffi position, then unplug the power cord from the wall outlet.

## WARNING

Before continuing with this procedure, review the Warning and Caution statements listed in Section One, Things You Should Know.

- 2. Remove the rear cover as described in Procedure 7.1.
- 3. Remove two screws from the bottom of the EFX frame that secure the power entry module mounting bracket to the frame. Swing the power entry module mounting bracket away from the frame to gain access to the on/off switch wiring.
- 4. Disconnect the wiring from the on/off switch.
- 5. Depress the mounting tabs that secure the switch to its mounting bracket. Remove the switch from its mounting position.

## Replacing the ON/OFF Switch

- 6. Make sure that the new on/off switch is set to the ioffi position. Position the switch assembly so that the label is facing up. Snap the switch assembly into the mounting bracket.
- 7. Refer to Wiring Diagram 8.1 or 8.5 for 120V units or Wiring Diagram 8.3 or 8.7 for 240V units and reconnect the switch wiring removed in step 4.
- 8. Fasten the power entry module mounting bracket to the EFX frame with the screws removed in step 3.
- 9. Re-install the rear cover as described in Procedure 7.1, then check the operation of the EFX as described in Section Four