



## Display Test Mode:

Models: 1800/1820

*Warning: Do not stand on the running belt while performing these tests.*

### I. Engaging Display Test Mode from

**Engineering Mode:** Use Display Test Mode to test the console LEDs, 15-segment displays, and the watchdog timer by way of the 1800/1820's own console controls and display.

- Press and hold the "SCAN", "TRACK/PROFILE" & "ELEVATION DOWN" keys together. While holding the "SCAN" & "ELEVATION DOWN" keys down, release the "TRACK/PROFILE" key.
- The display will beep and read:  
**ENGINEERING** *TRACK PROFILE*
- Press and release the "SCAN" key.
- Observe all the LEDs light up.

### Alternative to enter Display Test Mode:

- Turn the power switch on while pressing the "SCAN" key simultaneously on the display. *Track*
- The display will light up all the LEDs.

### II. Using Display Test Mode keys:

- **ELEVATION UP/DOWN KEYS:** Lights % grade LED's one at a time, also segments of 15-segment screen one at a time.
- **SPEED +/-:** Not applicable.
- **SCAN KEY:** Lights the six LEDs bordering the 15-segment display.
- **INFO RECALL OR HEART KEY:** Displays "HEART = XXX -" the XXX is the current averaged heart rate, and the - beats for every beat
- **START KEY:** Displays "START START" on the 15-segment display.
- **STOP KEY:** Displays "WD TEST" on the 15-segment display. Activates the watchdog timer, resetting the processor and returning the program back to Start Mode.
- **COOL DOWN KEY:** Displays "COOL DOWN"
- **TRACK/PROFILE KEY:** Displays "PROFILE"
- **PROGRAM KEY:** Displays "PROGRAM"